

# KOALA KARE PRODUCTS

## Installation and Operation Instructions

KB100-ST and KB110-SSRE Baby Changing Station

Cambiador Plegable

Table à Langer

Babywickeltisch



Your unit can be installed to meet ADA regulations when and where applicable. Refer to Federal Register, Volume 56, No 144 28 CFR Part 36.

You are responsible for the safe operation of this unit.

IMPORTANT. RETAIN FOR FUTURE REFERENCE. READ CAREFULLY.

IMPORTANTE. GUÁRDELO PARA FUTURAS CONSULTAS. LEER ATENTAMENTE.

IMPORTANT. A CONSERVER POUR INFORMATION. A LIRE ATTENTIVEMENT.

WICHTIG. ZUR SPÄTEREN BEZUGNAHME AUFBEWAHREN. BITTE SORGFÄLTIG DURCHLESEN.



PN 520  
June 2010

# OPERATING INSTRUCTIONS

## Please Note:

To assure proper installation, it is suggested that a qualified person or carpenter install the Koala Baby Changing Station. Koala Kare Products will not be responsible if the station is not installed properly.

Koala Baby Changing Stations have been tested to hold a substantial static load. The unit must be attached to a permanent wall that is capable of holding a substantial load.

## Inspection Criteria:

A properly maintained baby changing station:

- Opens and closes smoothly.
- Has both ends of a functioning, non-frayed strap: buckle clicks when closed and strap is attached at both ends of unit.
- Offers parents liners through a fully stocked liner dispenser. (Dispenser is built into unit.)
- Provides a clean, convenient place for customers to attend to their children.

## TOOLS NEEDED

Gloves	Phillips Head Screwdriver	Level	Pencil
Drill	1/8" Drill Bit	Measuring Tape	Stud Finder

## HARDWARE PROVIDED

Four 1/4" x 3" Phillips Panhead Wood Screws



Four 3/4" x 1/4" Flat Washers



# INSTALLATION INSTRUCTIONS

## Horizontal Baby Changing Station Recessed Mounted Model Numbers KB100-ST and KB110-SSRE

### Step 1.

Remove changing station from the shipping container and check for any freight damage. Identify the best location for installing the unit. Hold the unit in place and open the bed. Make sure you have taken the operating clearance into consideration.

### Step 2.

Select the wall area where the unit will be installed. Measure from the floor 46 1/2" (1117.6 mm) on stud center and mark the wall. Hold the unit in place to verify the alignment. Mark rough opening 35 1/2" W x 20 1/2" H (901.7 mm x 520.7 mm) and cut a hole in the wall with a minimum depth of 4 1/4" (108 mm) as measured from the finished surface of the wall (ie: tile, drywall, etc). Construct mounting frame as indicated in the illustration. If the wall surface is masonry or tile over wood studs, use caution when cutting rough opening.

### Step 3.

The unit will be mounted using four 1/4" x 3" wood screws through side holes as shown in illustration.

### Step 4.

Place the unit into the recessed area and use the side mounting holes as a guide to drill a pilot hole using a 1/8" drill bit. Insert the screws and flat washers through the side mounting holes to hold the unit in place. It may be necessary to adjust the level of unit by using a shim on the top right or left side of the unit before tightening securely to the studs.

### Step 5.

Position Koala sign (supplied) on the outside of the restroom door. Fill the built in dispenser with sanitary bed liners. Replacement parts and additional liners can be purchased from your local distributor or by calling toll free 888.733.3456 or 303.539.8300 in the U.S.

